

# System Configuration

2016/17

Sinar Photography AG • Farbhofstrasse 21 • CH 8048 Zürich  
contact@sinar.swiss • www.sinar.swiss • © Sinar Photography AG



System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.	
Sinar p3-df / Sinar eShutter Lenses	SB S 30 45	Sinarback S 30 45	01)	554.37.000	S09010	
		S 30 45 / Sinar Adapter Kit	7)	554.37.030	S09120	
		Sinar p3-df S 30 45		491.82.030	S01030	
			Sinar eShutter Control		552.15.001	S04620
			Sinar eShutter Control Bracket		552.15.020	S08003
			Sinar eShutter/S 30 45 Trigger Cable 50		440.18.265	S07013
	SB eVolution 86 H	Sinarback eVolution86 H	02)	552.45.005	S05005	
		SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133	
		Sinar p3-df		491.82.000	S01000	
LC Shutter 100		9)	551.65.020	S07010		
Sinar Power Supply 13.2V, 4m			523.11.053	S07030		
Sinar eShutter Control			552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)	16)	440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			
SB eXact	Sinarback eXact	02)	552.45.007	S05007		
	SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133		
	Sinar p3-df		491.82.000	S01000		
	LC Shutter 100	9)	551.65.020	S07010		
	Sinar Power Supply 13.2V, 4m		523.11.053	S07030		
	Sinar eShutter Control		552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)	16)	440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.	
Sinar rePro / Sinar eShutter Lenses	SB S 30 45	Sinarback S 30 45	01)	554.37.000	S09010	
		S 30 45 / Sinar Adapter Kit		554.37.030	S09120	
		Sinar rePro Universal		491.11.003	S02003	
			Sinar eShutter Control		552.15.001	S04620
			Sinar eShutter Control Bracket		552.15.020	S08003
			Sinar eShutter/S 30 45 Trigger Cable 50		440.18.265	S07013
	SB eVolution 86 H	Sinarback eVolution86 H	02)	552.45.005	S05005	
		SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133	
		Sinar rePro Universal		491.11.003	S02003	
LC Shutter 100		9)	551.65.020	S07010		
Sinar Power Supply 13.2V, 4m			523.11.053	S07030		
Sinar eShutter Control			552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)		440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			
SB eXact	Sinarback eXact	02)	552.45.007	S05007		
	SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133		
	Sinar rePro Universal		491.11.003	S02003		
	LC Shutter 100	9)	551.65.020	S07010		
	Sinar Power Supply 13.2V, 4m		523.11.053	S07030		
	Sinar eShutter Control		552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)		440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.	
Sinar rePro RC / Sinar eShutter Lenses	SB S 30 45	Sinarback S 30 45	01)	554.37.000	S09010	
		S 30 45 / Sinar Adapter Kit		554.37.030	S09120	
		Sinar rePro RC incl. Case 475.45.042	17)	491.11.020	S02020	
			Sinar eShutter Control		552.15.001	S04620
			Sinar eShutter Control Bracket		552.15.020	S08003
			Sinar eShutter/S 30 45 Trigger Cable 50		440.18.265	S07013
	SB eVolution 86 H	Sinarback eVolution86 H	02)	552.45.005	S05005	
		SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133	
		Sinar rePro RC incl. Case 475.45.042	17)	491.11.020	S02020	
LC Shutter 100		9)	551.65.020	S07010		
Sinar Power Supply 13.2V, 4m			523.11.053	S07030		
Sinar eShutter Control			552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)		440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			
SB eXact	Sinarback eXact	02)	552.45.007	S05007		
	SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133		
	Sinar rePro RC incl. Case 475.45.042	17)	491.11.020	S02020		
	LC Shutter 100	9)	551.65.020	S07010		
	Sinar Power Supply 13.2V, 4m		523.11.053	S07030		
	Sinar eShutter Control		552.15.001	S04620		
Sinar eShutter Control Bracket		552.15.020	S08003			
Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)		440.18.261	S07015			
LC Shutter/Sinarback Adapter Cable		551.65.021	S07011			

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar p3-df / CPL Lenses	SB 30 45	Sinar p3-df S 30 45	7)	491.82.030	S01030
		Sinarback S 30 45	01)	554.37.000	S09010
		S 30 45 / Sinar Adapter Kit		554.37.030	S09120
		Wake-Up Cable S 30 45		440.13.260	S07070
Sinar rePro / CPL Lenses	SB 30 45	Sinar rePro Universal		491.11.003	S02003
		Sinarback S 30 45	01)	554.37.000	S09010
		S 30 45 / Sinar Adapter Kit		554.37.030	S09120
		Wake-Up Cable S 30 45		440.13.260	S07070
Sinar lanTec / CEF Lenses	SB 30 45	Sinar lanTec (incl. Handgrips and Tripod Adaptation)	01)	493.23.006	S03006
		Sinarback S 30 45		554.37.000	S09010
		S 30 45 / Sinar Adapter Kit		554.37.030	S09120
		Wake-Up Cable S 30 45		440.13.260	S07070

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar p3 / Sinar CTM / Sinar eShutter Lenses	SB eVolution 86 H with Clear Glass Filter	Sinarback eVolution86 H with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar p3-df LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  9) 19) 20)	552.45.025 552.45.033 491.82.000 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05025 S07133 S01000 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011
	SB eXact with Clear Glass Filter	Sinarback eXact with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar p3-df LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  9) 19) 20)	552.45.027 552.45.033 491.82.000 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05027 S07133 S01000 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar rePro / Sinar CTM / Sinar eShutter Lenses	SB eVolution 86 H with Clear Glass Filter	Sinarback eVolution86 H with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar rePro Universal LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  9) 19) 20)	552.45.025 552.45.033 491.11.003 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05025 S07133 S02003 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011
	SB eXact with Clear Glass Filter	Sinarback eXact with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar rePro Universal LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  9) 19) 20)	552.45.027 552.45.033 491.11.003 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05027 S07133 S02003 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar rePro RC / Sinar CTM / Sinar eShutter Lenses	SB eVolution 86 H with Clear Glass Filter	Sinarback eVolution86 H with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar rePro RC incl. Case 475.45.042 LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  17) 9) 19) 20)	552.45.025 552.45.033 491.11.020 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05025 S07133 S02020 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011
	SB eXact with Clear Glass Filter	Sinarback eXact with Clear Glass Filter SB 54M-eXact/Sinar p3-rePro Adapter Kit Sinar rePro RC incl. Case 475.45.042 LC Shutter 100 Sinar CTM Slider Set (Slider + Software) Sinar CTM Slider / LC-Shutter Kit Sinar Power Supply 13.2V, 4m Sinar eShutter Control Sinar eShutter Control Bracket Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12) LC Shutter/Sinarback Adapter Cable	(02) 18)  17) 9) 19) 20)	552.45.027 552.45.033 491.11.020 551.65.020 551.65.010 551.65.011 523.11.053 552.15.001 552.15.020 440.18.261 551.65.021	S05027 S07133 S02020 S07010 S02010 S02011 S07030 S04620 S08003 S07015 S07011

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar p3-df RV / Sinar eShutter	Third-Party Digital Backs	Third-Party Digital Back with <b>HB-V</b> Interface Sinar p3-df RV Sinar p3/Hasselblad V Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket	10) 11)	491.82.020 556.64.030 552.15.001 552.15.020	S01020 S06082 S04620 S08003
		Third-Party Digital Back with <b>HB-H</b> Interface Sinar p3-df RV Sinar p3/Hasselblad H Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket	10) 11)	491.82.020 556.64.032 552.15.001 552.15.020	S01020 S06083 S04620 S08003
		Third-Party Digital Back with <b>M645</b> Interface Sinar p3-df RV Sinar p3/Mamiya 645 AF Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket	10) 11)	491.82.020 556.64.036 552.15.001 552.15.020	S01020 S06084 S04620 S08003
		Third-Party Digital Back with <b>HB-V</b> Interface Sinar p3-df RV Sinar p3/Hasselblad V Adapter Kit	10) 11)	491.82.020 556.64.030	S01020 S06082
		Third-Party Digital Back with <b>HB-H</b> Interface Sinar p3-df RV Sinar p3/Hasselblad H Adapter Kit	10) 11)	491.82.020 556.64.032	S01020 S06083
		Third-Party Digital Back with <b>M645</b> Interface Sinar p3-df RV Sinar p3/Mamiya 645 AF Adapter Kit	10) 11)	491.82.020 556.64.036	S01020 S06084

System Description	Digital Back Option	Recommended Items	Remarks	Sinar Item No.	Order No.
Sinar rePro / Sinar eShutter Lenses	Third-Party Digital Backs	Third-Party Digital Back with <b>HB-V</b> Interface Sinar rePro Universal Sinar p3/Hasselblad V Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.003 556.64.030 552.15.001 552.15.020	S02003 S06082 S04620 S08003
		Third-Party Digital Back with <b>HB-H</b> Interface Sinar rePro Universal Sinar p3/Hasselblad H Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.003 556.64.032 552.15.001 552.15.020	S02003 S06083 S04620 S08003
		Third-Party Digital Back with <b>M645</b> Interface Sinar rePro Universal Sinar p3/Mamiya 645 AF Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.003 556.64.036 552.15.001 552.15.020	S02003 S06084 S04620 S08003
		Third-Party Digital Back with <b>HB-V</b> Interface Sinar rePro RC incl. Case 475.45.042 Sinar p3/Hasselblad V Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.020 556.64.030 552.15.001 552.15.020	S02020 S06082 S04620 S08003
		Third-Party Digital Back with <b>HB-H</b> Interface Sinar rePro RC incl. Case 475.45.042 Sinar p3/Hasselblad H Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.020 556.64.032 552.15.001 552.15.020	S02020 S06083 S04620 S08003
		Third-Party Digital Back with <b>M645</b> Interface Sinar rePro RC incl. Case 475.45.042 Sinar p3/Mamiya 645 AF Adapter Kit Sinar eShutter Control Sinar eShutter Control Bracket		491.11.020 556.64.036 552.15.001 552.15.020	S02020 S06084 S04620 S08003
Sinar lanTec	Third-Party Digital Backs	Third-Party Digital Back with <b>HB-V</b> Interface Sinar lanTec (incl. Handgrips and Tripod Adaptation) Hasselblad-V Interface for Sinar lanTec/arTec	B)	493.23.006 493.23.294	S03006 S06307
		Third-Party Digital Back with <b>HB-H</b> Interface Sinar lanTec (incl. Handgrips and Tripod Adaptation) Hasselblad-H Interface for Sinar lanTec/arTec	B)	493.23.006 493.23.292	S03006 S06305
		Third-Party Digital Back with <b>M645</b> Interface Sinar lanTec (incl. Handgrips and Tripod Adaptation) Mamiya 645 AFD Interface for Sinar lanTec/arTec	B)	493.23.006 493.23.293	S03006 S06306

Lenses	Shutter System	Item Description	Remarks	Sinar Item No.	Order No.	
<b>Lenses</b>	<b>Sinar eShutter 250 (for Sinar p3 / rePro / rePro RC and third-party view cameras)</b>	Sinaron Digital HR 5.6/23 eShutter 250 (M72R)	4)	443.86.256	S04657	
		Sinaron Digital HR 4.5/28 eShutter 250 (M72R)	4)	443.86.258	S04658	
		Sinaron Digital HR 4.0/32 eShutter 250 (M86)	4)	443.86.259	S04659	
		Sinaron Digital HR 4.0/35 eShutter 250 (M67)	4)	443.86.260	S04660	
		Sinaron Digital HR 4.0/40 eShutter 250 (M67)	4)	443.86.262	S04661	
		Sinaron Digital 4.5/45 eShutter 250 (M67)	4)	443.86.203	S04650	
		Sinaron Digital HR 4.0/50 eShutter 250 (M67)	4)	443.86.263	S04662	
		Sinaron Digital 4.5/55 eShutter 250 (M67)	4)	443.86.205	S04651	
		Sinaron Digital HR 4.0/60 eShutter 250 (M49)	4)	443.86.264	S04663	
		Sinaron Digital HR 5.6/70 eShutter 250 (M58)	4)	443.86.207	S04652	
		Sinaron Digital HR SW 5.6/90 eShutter 250 (M72)		443.86.219	S04656	
		Sinaron Digital HR 4.0/100 eShutter 250 (M58)		443.86.268	S04664	
		Sinaron Digital macro 5.6/120 eShutter 250 (M49)	5)	443.86.211	S04653	
		Sinaron Digital HR 5.6/180 eShutter 250 (M67)		443.86.274	S04665	
		<b>Sinar eShutter (for Sinar p3 / rePro / rePro RC and third-party view cameras)</b>	Sinaron Digital HR 5.6/23 eShutter (M72R)	4)	443.86.156	S04607
			Sinaron Digital HR 4.5/28 eShutter (M72R)	4)	443.86.158	S04608
			Sinaron Digital HR 4.0/32 eShutter (M86)	4)	443.86.159	S04609
			Sinaron Digital HR 4.0/35 eShutter (M67)	4)	443.86.160	S04610
	Sinaron Digital HR 4.0/40 eShutter (M67)		4)	443.86.162	S04611	
	Sinaron Digital 4.5/45 eShutter (M67)		4)	443.86.103	S04600	
	Sinaron Digital HR 4.0/50 eShutter (M67)		4)	443.86.163	S04612	
	Sinaron Digital 4.5/55 eShutter (M67)		4)	443.86.105	S04601	
	Sinaron Digital HR 4.0/60 eShutter (M49)		4)	443.86.164	S04613	
	Sinaron Digital HR 5.6/70 eShutter (M58)		4)	443.86.107	S04602	
	Sinaron Digital HR SW 5.6/90 eShutter (M72)			443.86.119	S04606	
	Sinaron Digital HR 4.0/100 eShutter (M58)			443.86.168	S04614	
	Sinaron Digital macro 5.6/120 eShutter (M49)		5)	443.86.111	S04603	
	Sinaron Digital HR 5.6/180 eShutter (M67)			443.86.174	S04615	
	<b>CPL (Copal; for Sinar p3 / rePro)</b>		Sinaron Digital HR 5.6/23 CPL (M72R)	4)	443.83.156	S04307
			Sinaron Digital HR 4.5/28 CPL (M72R)	4)	443.83.158	S04308
			Sinaron Digital HR 4.0/32 CPL (M86)	4)	443.83.159	S04309
			Sinaron Digital HR 4.0/35 CPL (M67)	4)	443.83.160	S04310
		Sinaron Digital HR 4.0/40 CPL (M67)	4)	443.83.162	S04311	
		Sinaron Digital 4.5/45 CPL (M67)	4)	443.83.103	S04300	
		Sinaron Digital HR 4.0/50 CPL (M67)	4)	443.83.163	S04312	
		Sinaron Digital 4.5/55 CPL (M67)	4)	443.83.105	S04301	
		Sinaron Digital HR 4.0/60 CPL (M49)	4)	443.83.164	S04313	
		Sinaron Digital HR 5.6/70 CPL (M58)	4)	443.83.107	S04302	
		Sinaron Digital HR SW 5.6/90 CPL (M72)		443.83.119	S04306	
		Sinaron Digital HR 4.0/100 CPL (M58)		443.83.168	S04305	
		Sinaron Digital macro 5.6/120 CPL (M49)	5)	443.83.111	S04304	
		Sinaron Digital HR 5.6/180 CPL (M67)		443.83.174	S04315	
		<b>CEF Lenses (for Sinar IanTec)</b>	Sinaron Digital HR 5.6/23 CEF (M72R)		445.87.156	S00360
			Sinaron Digital HR 4.5/28 CEF (M72R)		445.87.158	S00361
			Sinaron Digital HR 4.0/32 CEF (M86)		445.87.159	S00362
			Sinaron Digital HR 4.0/35 CEF (M67)		445.87.160	S00363
	Sinaron Digital HR 4.0/40 CEF (M67)			445.87.162	S00364	
	Sinaron Digital 4.5/45 CEF (M67)			445.87.103	S00350	
	Sinaron Digital HR 4.0/50 CEF (M67)			445.87.163	S00365	
	Sinaron Digital 4.5/55 CEF (M67)			445.87.105	S00351	
	Sinaron Digital HR 4.0/60 CEF (M49)			445.87.164	S00366	
	Sinaron Digital HR 5.6/70 CEF (M58)			445.87.107	S00367	
	Sinaron Digital HR SW 5.6/90 CEF (M72)			445.87.119	S00368	
	Sinaron Digital HR 4.0/100 CEF (M58)			445.87.168	S00369	
	Sinaron Digital HR 5.6/180 CEF (M67)			445.87.174	S00370	

	Camera System	Item Description	Remarks	Sinar Item No.	Order No.
<b>Lens Conversions</b>	<b>Sinar p3 / rePro</b>	Conversion Sinaron Digital NON-HR DB/CMV/CAB/CPL in Sinar eShutter 25C		443.76.994	P7415
		Conversion Sinaron Digital HR DB/CMV/CAB/CPL in Sinar eShutter 25C		443.76.995	P7416
		Conversion Schneider Lenses in Sinar eShutter 25C		443.76.996	P7417
		---			
		Conversion Sinaron Digital NON-HR DB/CMV/CAB/CPL in Sinar eShutter		443.76.991	P7409
		Conversion Sinaron Digital HR DB/CMV/CAB/CPL in Sinar eShutter		443.76.992	P7410
		Conversion Schneider Lenses in Sinar eShutter		443.76.993	P7411
		---			
		Conversion eShutter to eShutter 250		443.76.997	P7420
		Lens Adjustment (optional; in combination with 443.76.997/P7420)		443.76.999	P7421
		---			
		Conversion Sinaron Digital DB/CMV/CAB to CPL (rec.B.; size 0 or 1)		443.73.997	P7400
Conversion Sinaron Digital DB/CMV/CAB to CPL (flat B.; size 0 or 1)		443.73.998	P7401		
<b>IanTec</b>	Conversion Sinaron Digital/Rodenstock Non-HR + HR CPL in CEF (according to released lenses)		443.75.991	P7402	
	Conversion Sinaron Digital/Rodenstock Non-HR DB/CMV/CAB to CEF (according to released lenses)		443.75.992	P7403	
	Conversion Sinaron Digital/Rodenstock HR DB/CMV/CAB to CEF (according to released lenses)		443.75.993	P7404	

Accessories / Spare Parts / Options	Lens Type	Item Description	Remarks	Sinar Item No.	Order No.	
Accessories / Spare Parts / Options	All shutter types	Adapter Ring 100/M49	3)	547.81.051	S08051	
		Adapter Ring 100/M58	3)	547.81.053	S08053	
		Adapter Ring 100/M67	3)	547.81.055	S08055	
		Adapter Ring 100/M72	3)	547.81.061	S08061	
		Adapter Ring 100/M72 R	3)	547.81.066	S08066	
		Adapter Ring 100/M86	3)	547.81.058	S08058	
		Cap for Lens Adapter Ring		547.81.002	S08042	
	Sinar eShutter Lenses	Sinar eShutter Control			552.15.001	S04620
		Sinar eShutter Control Bracket			552.15.020	S08003
		Sinar eShutter/S 30/45 Trigger Cable 50			440.18.265	S07013
		Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)			440.18.261	S07015
		Sinar eShutter/eVolution Trigger Cable 100 (RJ45 to RJ12)			440.18.271	S07017
		Sinar eShutter/eMotion Trigger Cable 50 (RJ45 to Lemo Trigger-In)			440.18.262	S07016
		Sinar eShutter/eMotion Trigger Cable 100 (RJ45 to Lemo Trigger-In)			440.18.272	S07018
		---				
		Sinar X-Contact Cable			440.18.263	S08000
		USB Cable for Sinar eShutter Control			440.18.264	S08001
	Recessed Lens Board eShutter			443.11.520	S08009	
	---					
	Sinarback Hand Cable Release			551.43.060	S07021	
	Sinar Power Supply 13.2V, 4m			523.11.053	S07030	
	Copal Lenses	Cable Release Copal Shutter (Spare Part)			444.91.000	S08035
		Wake-Up Cable S 30/45			440.13.260	S07070
		---				
		Lens Board 100, size 0			443.11.005	S08005
		Lens Board 100, size 1			443.11.006	S08006
	Lens Board 100, size 3			443.11.008	S08008	

Accessories / Spare Parts / Options	Camera System	Item Description	Remarks	Sinar Item No.	Order No.	
Accessories / Spare Parts / Options	Sinar p3	Wide Angle Bellows 100 EL		455.12.000	S06003	
		Multipurpose Bellows 100 EL, long		454.12.001	S06001	
		Multipurpose Standard 100		437.63.000	S06051	
		Multipurpose Bellows 100 EL		454.12.000	S06000	
		Rail Extension 6/15		421.21.000	S06042	
		Rail Extension 12/30		423.21.000	S06044	
		Basic Rail Unit 12/30		422.21.000	S06043	
		---				
		<b>Bellows Lens Hood - consisting of:</b>				
		Rod Holder 100			472.41.000	S06020
		Joint Rod 2			472.51.010	S06021
		Bellows Holder Clip			473.31.000	S06025
		Tapered Bellows 4x5/100			452.16.010	S06006
		Bellows-/ Filter Holder 100	21)		473.41.000	S06026
		---				
		Accessory Shoe			531.61.000	S06034
		---				
		Geared Rail Clamp	6)		411.71.000	S06041
		---				
		Carrier Frame 100, Rear Standard	12)		433.81.010	S06048
		Carrier Frame 100 RV, Rear Standard	13)		433.81.015	S06049
		Carrier Frame 100 S, Rear Standard	14)		433.81.020	S06052
		---				
	Sinar p3/Hasselblad V Adapter Kit	11)		556.64.030	S06082	
	Sinar p3/Hasselblad H Adapter Kit	11)		556.64.032	S06083	
	Sinar p3/Mamiya 645 AF Adapter Kit	11)		556.64.036	S06084	
	---					
	Pan Tilt Head 2			516.61.000	S06035	
	Reduction Adapter 4x5/100			553.15.100	S06080	
	---					
	Sinar rePro / rePro RC	Tripod Adaption Foba - Sinar rePro			491.11.012	S06210
		Universal Tripod Adaption - Sinar rePro			491.11.013	S06211
		Tripod Adaption Kaiser - Sinar rePro			491.11.014	S06212
		Sinar rePro RC Control Cable, 3 m			491.11.261	S06215
		Sinar rePro RC Control Cable, 10 m			491.11.262	S06216
		---				
		Sinar p3/Hasselblad V Adapter Kit	11)		556.64.030	S06082
Sinar p3/Hasselblad H Adapter Kit		11)		556.64.032	S06083	
Sinar p3/Mamiya 645 AF Adapter Kit		11)		556.64.036	S06084	
---						
<b>Bellows Lens Hood - consisting of:</b>						
Rod Holder 100				472.41.000	S06020	
Joint Rod 2				472.51.010	S06021	
Bellows Holder Clip				473.31.000	S06025	
Tapered Bellows 4x5/100			452.16.010	S06006		
Bellows-/ Filter Holder 100	21)		473.41.000	S06026		
---						
Sinar Parallel			711.01.000	S06095		

	Camera System	Item Description	Remarks	Sinar Item No.	Order No.
View Camera Conversion	Sinar p3 / p2 / x	Conversion Set Sinar p2/p3 (includes the following items: Carrier Frame 100, Rear Standard Carrier Frame 100, Front Standard Multipurpose Bellows 100 EL)		497.13.000	S06053
		Conversion Set Sinar p2/p3 RV (includes the following items: Carrier Frame 100 RV, Rear Standard Carrier Frame 100, Front Standard Multipurpose Bellows 100)		497.13.001	S06054
		Conversion Set Sinar p2/p3 S 30/45 (includes the following items: Carrier Frame 100 S 30/45, Rear Standard Carrier Frame 100, Front Standard Multipurpose Bellows 100)		497.13.002	S06061
		df-Conversion for Sinar p3/p2/x (The Sinar p3 must be sent in to Sinar service for this conversion)		497.12.000	P7405
		Conversion Set Sinar p3/p3-slr-N		497.13.010	S06055
		Conversion Set Sinar p3/p3-slr-C		497.13.020	S06056
Conversion Set Sinar p3/p3 MF-L		497.13.050	S06059		

	Camera System	Item Description	Remarks	Sinar Item No.	Order No.
Accessories / Spare Parts / Options	Sinar IanTec	Hasselblad-H Interface for Sinar IanTec/arTec		493.23.292	S06305
		Mamiya 645 AFD Interface for Sinar IanTec/arTec		493.23.293	S06306
		Hasselblad-V Interface for Sinar IanTec/arTec		493.23.294	S06307
		---			---
		Accessory Shoe Sinar IanTec	15)	531.62.000	S06312
		LC Shade p3 / IanTec / arTec		493.23.041	S06303

	Digital Backs	Item Description	Remarks	Sinar Item No.	Order No.
Accessories / Spare Parts / Options	Sinar Digital Backs	<b>Accessories for Sinarback eVolution/eXact</b>			
		SB 54M-eXact/Sinar p3-rePro Adapter Kit		552.45.033	S07133
		SB 54M-eXact/Mamiya 645 AFD Adapter Kit		552.45.045	S07145
		SB 54M-eXact/Hasselblad GEN Adapter Kit		552.45.050	S07150
		SB 54M-eXact/Hasselblad H Adapter Kit		552.45.053	S07153
		LC Shutter 100		551.65.020	S07010
		LC Shutter/Sinarback Adapter Cable		551.65.021	S07011
		Sinar eShutter/eVolution Trigger Cable 50 (RJ45 to RJ12)		440.18.261	S07015
		Sinar eShutter/eVolution Trigger Cable 100 (RJ45 to RJ12)		440.18.271	S07017
		Cable Firewire 1394B, 4.5 m		551.63.055	S07054
		Sinar Power Supply 13.2V, 4m		523.11.053	S07030
		---			---
		<b>Accessories for Sinarback S 30i45</b>			
		S 30i45 / Sinar Adapter Kit		554.37.030	S09120
		Sinar eShutter/S 30i45 Trigger Cable 50		440.18.265	S07013
		Wake-Up Cable S 30i45		440.13.260	S07070
		Quick Charger S		16009	16009
		Battery BP-PRO1 for Sinarback S 30i45		16039	16039
		USB 3.0 - Cable S 30i45		16040	16040
		AC-Adapter S 30i45		16041	16041
		Audio-Adapter S 30i45		16042	16042
		Remote release cable S 30i45		16029	16029
		HDMI cable 1.5 m		14491	14491
		Professional Battery Charger for S 30i45		16011	16011
		---			---
		<b>Accessories for all Sinarbacks</b>			
		White Shading Diffusor 100		551.43.097	S07043
		White Shading Diffusor 100x100 (Slide-In for LC Shutter)		551.43.096	S07042
		Digital Cleaning Kit		551.33.090	S07040
		Micro Fiber Cleaning Cloths, 10 pcs.		149.14.010	S07041

Explanation of Indexes	
1	Including USB cable, Battery, Battery Charger, White Shading Diffusor, USB Stick with Software
2	Including FireWire cable, Digital Cleaning Kit, Grey Card, White Shading Diffusor, Software CD incl. White Shading
3	This ring is required to mount any auxiliary accessories on the lens (e.g. LC Shutter 551.65.020, White Shading Diffusor 551.32.097, Bellows-/Filter Holder 473.41.000, Lens Shade 493.23.041, etc.)
4	When working with this lens, the use of a Wide Angle Bellows 100 EL 455.12.000 is required on Sinar p3 camera systems.
5	Note for use on Sinar p3 systems: For images with a scale of reproduction of 1:1 the use of a Multipurpose Bellows 100 EL (long) 454.12.001 is required to achieve the necessary bellows extension.
6	For images with a scale of reproduction of 2:1 the use of two Multipurpose Bellows 100 EL 454.12.000 and a Multipurpose Standard 100 437.63.000 are required to achieve the necessary bellows extension.
7	For a smooth lateral tilting of the camera. Requires two Rail Extensions 421.21.000 or 423.21.000 (15 or 30 cm)
8	The Sinar p3 S 30i45 differs from the Sinar p3 in the rear carrier frame and the Multipurpose Bellows 100. The modified carrier frame of the Sinar p3 S 30i45 grants the swing and tilt axis of the camera to be on the image plane of the Sinar S 30i45. The Sinar p3 S 30i45 rear carrier frame is also available separately.
9	The cable connecting the X-contact of the lens with the digital back has to be provided by the supplier of the digital back
10	This item is mounted in front of the lens with the auxiliary of a Lens Adapter Ring (ring size depending on the used lens)
11	The Sinar p3 RV differs from the Sinar p3 in the rear carrier frame and the Multipurpose Bellows 100. The modified carrier frame of the Sinar p3 RV grants the swing and tilt axis of the camera to be on the image plane of the Non-Sinar digital back. The Sinar p3 RV rear carrier frame is also available separately.
12	Adaptation for Third-Party Digital Backs on a Sinar p3-df RV and Sinar rePro/RC.
13	Used to convert a Sinar p2 to a Sinar p3
14	Used to convert a Sinar p2 to a Sinar p3 RV
15	Used to convert a Sinar p2 to a Sinar p3 S 30i45
16	This Lens Shade is mounted on the lens by means of an appropriated lens adapter ring
17	Scale of reproduction 1:1 and higher requires 440.18.271.
18	Including camera, Multipurpose Bellows 100 EL long, rePro RC Control Cable 3m, rePro RC Control Interface, Power Supply
19	Sinarback is equipped with Clear Glass Filter instead of IR Filter
20	Software is licensed and protected by dongle (included in scope of delivery)
21	Necessary to mount and to use LC-Shutter in combination with CTM Slider
22	Not required if using LC Shutter